



SPRAY EQUIPMENT PROCEDURE

CLOSE DOWN AND CLEAN OUT EVERY DAY

1. Reduce fluid pressure – **atomising air off completely.**
2. Remove siphon tube from paint/stain, brush off excess and place tube in water.
3. Remove tip from gun and place in small container of water.
4. Open circulating pump tap and drain paint/stain until water runs through.
5. Unlock trigger from gun and drain paint/stain until water runs through.
6. Turn off air supply to pump, release pressure through circulating pump and check gun to ensure no pressure in system.
7. Remove filter at inlet pipe, main filter and gun filter and clean thoroughly. Replace clean filters and tighten.
8. Repeat steps 4 & 5 until clean water runs through pump and line.
9. Thoroughly clean tip and replace on gun – trigger lock on!

REMEMBER

- ❖ **Warm but not hot water may be used**
- ❖ **Liquid detergent or preferably Sikkens ST830 may be used at step 7**
- ❖ **Take care when cleaning, dirty water can easily splash into eyes**
- ❖ **DO NOT DIRECT GUN AT ANYONE**

